


LANE #1

DIFFERENCE


Drilling Instructions

Track Flare Bowtie is measured from the MB through the pin..!!




Place pin below the fingers, not more than 1/2 distance between midline and bottom of fingers.

Track Flare Bowtie is measured from the MB through the pin..!!



For an earlier roll, or for PAP's less than 4 3/4", lower the pin and/or swing the MB out farther to the right.


Track Flare Bowtie is measured from the MB through the pin..!!



Higher tracks, shift grip slightly left of pin, placing the pin under the ring finger area, for more hook.

Hints

For balls with low starting top, place balance hole, on a line from the Center of Grip, through the MB, extending out 10" from Center of Grip.




Do Not place the MB angle to the midline more than 45°.

Place balance hole wherever necessary to end with the desired ending static weights.

Balls with shorter pins and/or for an earlier roll, place balance hole between MB and midline. For pin in balls, and/or to not add more finger weight, place balance hole on the midline.

Balls with CG Left or CG right will use different balance hole locations to get to the desired ending static weights.



For Answers To Any Questions On Drilling, Please Call...

Lane #1 Tech Support

1-800-526-3661

Updated 10/6/15